

Notebook Connector Compatibility List

Tip	V	Manufacturer	Model	Tip	V	Manufacturer	Model	Tip	V	Manufacturer	Model																																									
E	19V	Acer	Aspire One Series: 531h 10.1", 531h-1440, 531h-1766, 751h 11.6", 751h-1021, 751h-1080, 751h-1145, 751h-1153, 751h-1192, 751h-1196, 751h-1211, 751h-1259, 751h-1273, 751h-1279, 751h-1346, 751h-1351, 751h-1373, 751h-1378, 751h-1401, 751h-1442, 751h-1522, 751h-1545, 751h-1893, 751h-1948, A110-1041, A110-1113, A110-1137, A110-1178, A110-1295, A110-1545, A110-1588, A110-1626, A110-1662, A110-1691, A110-1698, A110-1722, A110-1812, A110-1831, A110-1834, A110-1888, A110-1948, A110-1955, A110-1995, A150-1001, A150-1006, A150-1029, A150-1035, A150-1049, A150-1068, A150-1083, A150-1126, A150-1137, A150-1141, A150-1172, A150-1178, A150-1220, A150-1249, A150-1316, A150-1329, A150-1347, A150-1348, A150-1359, A150-1382, A150-1400, A150-1405, A150-1423, A150-1435, A150-1444, A150-1447, A150-1457, A150-1485, A150-1493, A150-1504, A150-1505, A150-1532, A150-1546, A150-1553, A150-1555, A150-1570, A150-1572, A150-1576, A150-1577, A150-1588, A150-1622, A150-1635, A150-1649, A150-1662, A150-1672, A150-1679, A150-1690, A150-1706, A150-1742, A150-1777, A150-1784, A150-1786, A150-1798, A150-1834, A150-1864, A150-1887, A150-1890, A150-1905, A150-1949, A150-1983, A150-1987, A150-1995, A150-1997, D150-1044, D150-1125, D150-1165, D150-1186, D150-1197, D150-1240, D150-1322, D150-1462, D150-1577, D150-1587, D150-1606, D150-1647, D150-1669, D150-1739, D150-1860, D150-1920, D250 10.1", D250-1026, D250-1042, D250-1116, D250-1132, D250-1151, D250-1165, D250-1185, D250-1196, D250-1288, D250-1289, D250-1302, D250-1326, D250-1580, D250-1610, D250-1706, D250-1724, D250-1738, D250-1797, D250-1905, D250-1924, D250-1990, ZG5, ZG-5 Aspire: 1825 Series, 1825PTZ, 1820PTZ, 1810T Series, 1420P Series, 1410	R	19V	ASUS(C)	F201E SERIES, F201E-KX052H, F201E-KX063H, F201E-KX064H, F201E-KX065DU, F201E-KX065H, F201E-KX066DU, F201E-KX066H, F201E-KX067DU, F201E-KX067H, F201E-KX068DU, F201E-KX068H, F202E SERIES, F202E-CT028H, F202E-CT059H, F202E-CT063H, F202E-CT133H, F202E-CT148H, Q200E SERIES, Q200E-BH13T45, S200E-CT157H, S200E-CT158H, S200E-CT182H, S200E-CT57H, S200E-RH13T73, Special Edition VivoBook X202E Pink, Taichi 21TAICHI 21 SERIES, TAICHI 21-CW001H, TAICHI 21-CW001P, TAICHI 21-CW002H, TAICHI 21-CW003H, TAICHI 21-CW004H TAICHI 21-CW005P, TAICHI 21-CW009H, Taichi 21-DH51 UX21A Series UX21A, UX302 Series UX301LA/UX302LA UX302LG, UX31A Series UX31A-1AR4/UX31A-1AR5/UX31A-1AR7, UX31A-AB71/UX31A-AB72, UX31A-BH15T11, UX31A-DB51/DB52/DB71/DB72, UX31A-DH51/DH71/DH71-CA/DH71-CB, UX31A-R4002V/R4003V/R4003X/R4004V/R4005V, UX31A-R4005X, UX31A-R5007V, UX31A-R5008V/R5102F/R5102H/R5202H, UX31A-R7202F, UX31A-RB71, UX31A-XB52/XB72, UX-32A Series UX32A-DB31/DB51/DB71, UX32A-R3001V/R3002V/R3007V/R3008/R3013V/R3502H, UX32VD Series UX32VD-BH15N57/BH17N55, UX32VD-DB51/DB71/DB72 UX32VD-DH71, UX32VD-R3001H/R3001V/R3001X, UX32VD-R4002H/R4002P/R4002V/R4002X/R4006V, UX32VD-R4331V, UX32VD-R5504H/R7504F	G	19V	Hp	Mini 700 Series: 700EA, 700ED, 700EE, 700EF, 700EI, 700EK, 700EL, 700EN, 700ER, 700ES, 700ET, 700EW, 701ED, 701EG, 701EI, 701EM, 701EN, 701ER, 701ES, 701ET, 702, 703, 705, Mini 1000 Series: 1000 CTO, 1001TU, 1001XX, 1002TU, 1003TU, 1004TU, 1005TU, 1006TU, 1007TU, 1008TU, 1009TU, 1010LA, 1010NR, 1010TU, 1011TU, 1012TU, 1013TU, 1014TU, 1015TU, 1016TU, 1017TU, 1020LA, 1021TU, 1022TU, 1023TU, 1024TU, 1030NR, 1033CL, 1035NR, Mini 1100 Series: 1100CM, 1101TU, 1102TU, 1103TU, 1104TU, 1105TU, 1106TU, 1107TU, 1108TU, 1109TU, 1110LA, 1110NR, 1110TU, 1112TU, 1113TU, 1114TU, 1115NR, 1123TU, 1124TU, 1125NR, 1125TU, 1126NR, 1126TU, 1127TU, 1129TU, 1130CM, 1131TU, 1133CA, 1135CA, 1137NR, 1139NR, 1140NR, 1141NR, 1150BR, 1150CM, 1150LA, 1150NR, 1151NR, 1152NR, 1153NR, 1160CM, 1170CM, 1180CM, 1190BR, 1115TU, 1116NR, 1116TU, 1117TU, 1118TU, 1119TU, 1120BR, 1120LA, 1120NR, 1120TU, 1121TU, 1122TU, Mini 210 Series.	Q	19V	IBM/LENOVO	Thinkpad 2080, Carbon X1, Helix 3697, 3698, 3700, 3701, 3702, X240, S431, S531, S540, S540 Touch, T431S, T440, T540, Tiny 73, 93	S	19V	HP	Folio 1040 G1 G2, Elitebook (19.5V) 2530/2730P/6930P/8530PW/8730W	P	19V	ATIV SMART PC PRO Series 7	XE700T1A, XE700T1A-A01US, XE700T1A-A03US, XE700T1A-A04US, XE700T1A-A05US, XE700T1A-A06US, XE700T1A-A01, XE700T1A-A02, XE700T1A-A04, XE700T1A-A05	Tip	V	MSI	U Series: U100-001US, 002US, 004US, 013US, 016US, 018US, 030US, 035US, 036US, 039US, 043US, 053US, 219US, 222MY, 244MY, 279US, 280US, 286MY, 411US, 420US, 422CA, 427US, 432US, 439US, 451US, 631US, 641US, 843US, 869US, 876US, U110-031US, U115-021US, U120-001US, 020US, 024US, U123-001US, 002US, 003US, 004US, 019US, 020US, 025US, 033US, U130-416US, 417US, U135-204US, 205US, 206US, 208US, 210US, 411US, 413US, 415US, 628US, 643US, 644US, U135-204US, 205US, 206US, 208US, 210US, 411US, 413US, 415US, 628US, 643US, 644US, U135DX-1208US, U160-006US, 007US, U210-006US, 008US, U230-033US, 040US, U230 Light-087US, L Series: L1300-441US L1350-430US, 431US, 436US, 437US, L2100-036US, L2300-038US, X Series (Slim): X320, X340, X350, X360, X400, X410, X420, X430, X480	C	20V	MSI	U Series: U100-001US, 002US, 004US, 013US, 016US, 018US, 030US, 035US, 036US, 039US, 043US, 053US, 219US, 222MY, 244MY, 279US, 280US, 286MY, 411US, 420US, 422CA, 427US, 432US, 439US, 451US, 631US, 641US, 843US, 869US, 876US, U110-031US, U115-021US, U120-001US, 020US, 024US, U123-001US, 002US, 003US, 004US, 019US, 020US, 025US, 033US, U130-416US, 417US, U135-204US, 205US, 206US, 208US, 210US, 411US, 413US, 415US, 628US, 643US, 644US, U135DX-1208US, U160-006US, 007US, U210-006US, 008US, U230-033US, 040US, U230 Light-087US, L Series: L1300-441US L1350-430US, 431US, 436US, 437US, L2100-036US, L2300-038US, X Series (Slim): X320, X340, X350, X360, X400, X410, X420, X430, X480	F	19.5V (19V)	Mini 311 Series, Mini 5100 Series		Tip	V	Asus	Eee PC: 701/7015D, 2G, 2G Surf, 4G, 4G Surf, 8G	M	19V	HP 2133 Mini-Note PC, 2533H Mobile Thin Client, HP Compaq 2230s, 2510p, 2710p, 6530b, 6720s, 6720t Mobile Thin Client, 6730b, 6730s, 6735s, nc2400, nc4200, nc4400, nc6120, nc6140, nc6220, nc6230, nc6320, nc6400, nx6110, nx6115, nx6325, nx7300, nx7400, tc4200 Tablet PC, tc4400 Tablet PC, EliteBook 2530p, EliteBook 2730p, Pavilion Dv4-1000 Series, DV4-1000, DV4T-1000, DV4Z-1000 CTO, Pavilion DV5-1000 Series, DV5-1120US, DV5-1124CA Pavilion Dv7	N	19V	Asus Eee PC 1005HA Series, 1005, 1005H, 1005HA, 1005HA-A, 1005HAB, 1005HA-E, 1005HA-P, 1005HA-V, 1005HA-EU1X, 1005HA-EU1X-BK, 1005HA-PUIX, 1005HA-PUIX-BK, 1005HA-PUIX-BK, 1005HA-PUIX-BK, 1005HA-VU1X-BK, 1005HA-VU1X-WT, 1005HA-VU1X-BU, 1005HA-VU1X-PI. 1008HA Series, 1101HA Series, 1101HA, 1101HGO, 101HA-MU1X, 101HA-MU1X-BK, 1104HA Series, 1106HA Series, 1001P, 1001HA	Tip	V	Lenovo	IdeaPad: S9, S9e, S10-2 (10"), S10-3 (10"), S10-3t, S10C, S10e, S12 (12"), U150 (11"), U160 ThinkPad: X100e (11"), X201 (12"), X201i	P	19.5V (19V)	Eee Pad B121, B121-A1, EP121, Eee (19V) Slate B121, B121-A1, Ep121
P	12V	Iconia A	A100, A101, A200, A210, A211, A500, A501, A511, A700, A701	Tip	V	Dell	Inspiron Mini: 9, 10, 10v, 12, 910, 1010, 1011, 1012, 1210, P04t, PP19s, PP39s, PP40s, Nickelodeon Vostro: A90, PP39S	Tip	V	Fujitsu	Lifebook mini: MH330, MH380, M2010, M2011																																									
Tip	V	Gateway	LT 10 Series: 1001, 1004u, 1005, 1005u, LT 20 Series: 2001U, 2002i, 2003i, 2005U, 2012, 2012H, 2013, 2013H, 2016U, 2021U, 2022U, 2023U, 2024U, 2027H, 2028H, 2030U, 2032U, 2033U, 2036U, 2041U, 2044U, LT 21 Series: 2100, 2101, 2102H, 2103H, 2104U, 2106H, 2106U, 2107H, 2108U, 2110U, 2113U, 2114U, 2115U, 2118U, 2119U, 2120U, 2122U, 2123U, LT 22 Series /LT 23 Series: 2315U, 2316U, 2318U, 2319U, 2320U, 2321U, LT 30 Series: 3005U, LT 31 Series: 3101U, 3102i, 3103U, 3104E, 3104G, 3105G, 3107U, 3108H, 3110H, 3111H, 3113H, 3114U, 3115H, 3116H, 3117U, 3118U, 3119U, LT 32 Series: 3200, 3201U, EC Series: EC14, EC1400, EC18, EC1800																																																	



Notebook Connector Compatibility List

Tip	V	Manufacturer	Tip	V	Manufacturer	Tip	V	Manufacturer	Tip	V	Manufacturer
C	19V	Toshiba	E	19V	Acer	E	19V	Acer	E	19V	Acer
<p>AC Series (UK): AC100, Mini NB Series: NB100, NB105, NB200 Series, NB200-00C, NB200-00D, NB200-00P, NB200-10F, NB200-10G, NB200-10J, NB200-10Z, NB200-110, NB200-113, NB200-11H, NB200-11L, NB200-13T, NB202-107, NB205-N210, NB205-N211, NB205-N230, NB205-N310/BN, NB205-N310BNG, NB205-N311/W, NB205-N312/BL, NB205-N313/P, NB205-N323BN, NB205-N324BL, NB205-N324WH, NB205-N325BN, NB205-N325PK, NB205-N325WH, NB205-N330BL, NB205-N330BN, NB205-N330PK, NB205-N330WH, NB205-SP2920, NB205-SP2921, NB205-SP2922, NB205-SP2923, NB205-SP2924, NB255-N240, NB255-N245, NB255-N250, NB305-N310, NB305-N310G, NB305-N410BL, NB305-N410BN, NB305-N410BN-G, NB305-N410WH, NB305-N411BL, NB305-N413BN, NB305-N415BL, NB305-SP1051, NB305-SP1052, NB305-SP2001, NB305-SP2002, NB350-N310, NB350-N410</p>			<p>AcerNote: ACERNOTE 350 SERIES, ACERNOTE LIGHT 360, ACERNOTE 367, ACERNOTE 3680, ACERNOTE 370 SERIES, ACERNOTE LIFENOTE 373, ACERNOTE 380, ACERNOTE 382, ACERNOTE 390, ACERNOTE 850C Aspire: Aspire 1411 Series, Aspire 1412 Series, Aspire 1413 Series, Aspire 1414 Series, Aspire 1415 Series, Aspire 1450, Aspire 1640 Series, Aspire 1640Z series, Aspire 1641 series, Aspire 1650 Series, Aspire 1651 Series, Aspire 1690 Series, Aspire 1691 Series, Aspire 1692 Series, Aspire 1693 Series, Aspire 1694 Series, Aspire 1695 Series, Aspire 2000 Series, Aspire 2420 Series, Aspire 2920 Series, Aspire 2930, Aspire 3000 Series, Aspire 3020, Aspire 3050 Series, Aspire 3100 Series, Aspire 3510, Aspire 3610, Aspire 3620 Series, Aspire 3640, Aspire 3660 Series, Aspire 3670, Aspire 3680 Series, Aspire 3690 Series, Aspire 3810 Timeline Series, Aspire 3820 Timeline Series, Aspire 3935, Aspire 4230, Aspire 4310, Aspire 4330 Series, Aspire 4520, Aspire 4530, Aspire 4551 Series, Aspire 4710, Aspire 4720, Aspire 4730, Aspire 4741 Series, Aspire 4771 Series, Aspire 4810 Timeline Series, Aspire 4820 Timeline Series, Aspire 4920, Aspire 4930, Aspire 5000 Series, Aspire 5020, Aspire 5030 Series, Aspire 5040 Series, Aspire 5050 Series, Aspire 5100 Series, Aspire 5110 Series, Aspire 5230 Series, Aspire 5235 Series, Aspire 5310 Series, Aspire 5315 Series, Aspire 5330 Series, Aspire 5500 Series, Aspire 5510 Series, Aspire 5520 Series, Aspire 5520G Series, Aspire 5530 Series, Aspire 5530G Series, Aspire 5535 Series, Aspire 5550 Series, Aspire 5560 Series, Aspire 5570 Series, Aspire 5580 Series, Aspire 5590, Aspire 5600 Series, Aspire 5610 Series, Aspire 5620 SERIES, Aspire 5630 Series, Aspire 5650 Series, Aspire 5670 SERIES, Aspire 5680 Series, Aspire 5710 Series, Aspire 5715Z Series, Aspire 5720 Series, Aspire 5730Z Series, Aspire 5735 Series, Aspire 5739G Series, Aspire 5741 Series, Aspire 5810 Timeline Series, Aspire 5820 Timeline Series, Aspire 5920 Series, Aspire 5920G Series, Aspire 5930 Series, Aspire 6530 Series, Aspire 6530G Series, Aspire 6920 Series, Aspire 6920G Series, Aspire 6930 Series, Aspire 6935 Series, Aspire 7000 Series, Aspire 7100 Series, Aspire 7110 Series, Aspire 7220 Series, Aspire 7230 Series, Aspire 7330 Series, Aspire 7520 Series, Aspire 7530 Series, Aspire 7720 Series, Aspire 7730 Series, Aspire 8730 Series, Aspire 8920 Series, Aspire 8930 Series, Aspire 9100 Series, Aspire 9110 Series, Aspire 9120 Series, Aspire 9300 Series, Aspire 9400 Series, Aspire 9410 Series, Aspire 9420, Aspire 9500 Series, Extensa: EXTENSA 360 SERIES, EXTENSA 390 SERIES, EXTENSA 500 Series, EXTENSA 600 SERIES, EXTENSA 900, EXTENSA 2300, Extensa 4420 Series, Extensa 4620 Series, Extensa 4630 Series, Extensa 5210 Series: Extensa 5220 Series, Extensa 5230 Series, Extensa 5420G Series, Extensa 5620Z Series, Extensa 5630 Series, Extensa 5630G Series, Extensa 7220 Series, Extensa 7620 Series</p>			<p>TravelMate 261 Series, TravelMate 261XV-XP Series, TravelMate 270 Series, TravelMate 270XV Series, TravelMate 280 Series, TravelMate 290 Series, TravelMate 290E Series, TravelMate 291 Series, TravelMate 29X Series, TRAVELMATE 320 SERIES, TRAVELMATE 330 SERIES, TRAVELMATE 340 SERIES, TRAVELMATE 350 SERIES, TRAVELMATE 360 SERIES, TravelMate 370 Series, TravelMate 371 series, TravelMate 380 Series, TRAVELMATE 420 SERIES, TRAVELMATE 430 SERIES, TRAVELMATE 505 SERIES, TRAVELMATE 506 SERIES, TRAVELMATE 507 SERIES, TRAVELMATE 508 SERIES, TRAVELMATE 510 SERIES, TRAVELMATE 530 SERIES, TRAVELMATE 550 SERIES, TRAVELMATE 600 SERIES, TRAVELMATE 610 SERIES, TRAVELMATE 620 SERIES, TRAVELMATE 630 SERIES, TravelMate 650, TravelMate 660, TRAVELMATE 710 SERIES, TRAVELMATE 720 SERIES, TRAVELMATE 730 SERIES, TRAVELMATE 740 SERIES, TravelMate 800, TravelMate C100 Series, TravelMate C102 Series, TravelMate C104 Series, TravelMate C110 Series, TravelMate C200 Series, TravelMate C210 Series, TravelMate C300 Series, TravelMate C310 Series, TRAVELMATE K550 SERIES, TravelMate 2300 Series, TravelMate 2310 Series, TravelMate 2350 Series, TRAVELMATE 2400 SERIES, TravelMate 2410 Series, TravelMate 2420 Series, TravelMate 2430, TravelMate 2440 Series, TravelMate 2450 Series, TravelMate 2460, TravelMate 2470, TravelMate 2480 Series, TravelMate 2490 Series, TravelMate 3000, TravelMate 3010 Series, TRAVELMATE 3020 SERIES, TRAVELMATE 3030 SERIES, TRAVELMATE 3040 SERIES, TRAVELMATE 3200 SERIES, TravelMate 3240 Series, TravelMate 3250 Series, TravelMate 3270 Series, TravelMate 3280 Series, TRAVELMATE 3290 SERIES, TravelMate 3300 Series, TravelMate 3900 Series, TravelMate 4000 Series, TravelMate 4010 Series, TravelMate 4020 Series, TravelMate 4050 Series, TravelMate 4060 Series, TravelMate 4070, TravelMate 4080, TravelMate 4100 Series, TravelMate 4150 Series, TravelMate 4200 Series, TravelMate 4210, TravelMate 4220 Series, TravelMate 4230 Series, TravelMate 4260 Series, TravelMate 4280 Series, TravelMate 4310, TravelMate 4320, TravelMate 4400 Series, TravelMate 4500 Series, TravelMate 4520, TravelMate 4600, TravelMate 4650 Series, TRAVELMATE 4670 SERIES, TravelMate 5100 Series, TravelMate 5210 Series, TravelMate 5220 Series, TravelMate 5230 Series, TravelMate 5310 Series, TravelMate 5320 Series, TravelMate 5510 Series, TravelMate 5520 Series, TravelMate 5530 Series, TravelMate 5710 Series, TravelMate 5720 Series, TravelMate 5730 Series, TravelMate 5740 Series</p>			<p>TravelMate 6000, TravelMate 6231 Series, TravelMate 6252, TravelMate 6291 Series, TravelMate 6292 Series, TRAVELMATE 6410 SERIES, TRAVELMATE 6460 SERIES, TravelMate 6492 Series, TRAVELMATE 6500 SERIES, TravelMate 6592 Series, TravelMate 6553 SERIES, TravelMate 7220 Series, TravelMate 7320 Series, TravelMate 7510, TravelMate 7520 Series, TravelMate 7720 Series, TravelMate 8000 Series, TravelMate 8100 Series, TravelMate 8200 Series, TravelMate 8210 Series, TravelMate Timeline 8371 Series, TravelMate Timeline 8471 Series, TravelMate Timeline 8571 Series Ferrari: Ferrari 1000 Series, Ferrari 1100, FERRARI 3000 SERIES, FERRARI 3200 SERIES, FERRARI 3400 SERIES, Ferrari 4000 Series</p>		
B	15V	Portege Series: 2000 Series, 4000 Series, 4010 Series, M100 Series, M300 Series, R100 Series, Tecra Series: 9000 Series, 9100 Series, 5, Satellite Series: 230 series, 300 series, 1555, 2060, 2100 series, 2200 series, 2500 Series, 2600 Series, 2710, 2750, 2770, 4000 Series, Pro 300 Series, Pro 400 Series, Pro 440 Series, Pro 460 Series, Pro 470, Pro 480, Pro 490, Pro 4200 Series, Pro 4300 Series, Pro 4600 Series									
A	10.5V	Sony									
<p>VPC-W Series, W111XU, W111XX, P, PC, T, W, W112XX, P, T, W, W115XG, W115XGP, W115XW, P, T, W, W117XC, P, T, W, W119XJ, P, W, W11AXJ, W1151E, P, T, W, W121AX, P, Q, T, W, WZ, W126AG, W127JC, P, T, W, WZ, W12AAJ, W12AKJ, W12AVJ, W1251E, P, T, W, W211AX, L, P, T, W, W212AX, W1, W215AX, L, P, T, W, W216AG, W217JC, L, P, T, W, W218JC, L, P, T, W, W219AJ, L, P, W, W21AAJ, W21AKJ, W21AVJ, W221AX, VPC-M Series, Model, M11M1E, B, W, M12M1E, L, P, W,</p>											
F	19.5V (19V)	VGN-P Series: P11Z, G, Q, R, W, P13GH, Q, W, P15G, G, Q, R, W, P17H, G, Q, R, W, P19VN/Q, P19WN/Q, P215/W, P31ZK, Q, R, P33GK, P35GK, P39VL/Q, P45GK, N, P, Q, W, P50, G, R, W, P530CH, G, Q, R, W, P530H, G, Q, R, W, P530N, Q, P588E, Q, R, P598E, Q, P610, G, N, Q, R, W, P615, P688E, G, N, Q, R, W, P698E, Q, R, P699E, Q, R, P70H, G, R, W, P720K, Q, R, P72K/W, P788K, G, N, P, Q, R, W, P798K, Q, P799L, Q, P80H/W, P90HS, P90NS, P90S, P91HS, P91NS, P91S, P92KS, P92LS, P92VS, VPC-P Series: P111KX, B, D, G, P, W, P113KX, B, D, G, P, W, P114KX, B, D, G, P, W, P115JC, B, D, G, P, W, P115KG, P116KX, B, D, G, P, W, P116KG, P118JC, B, P, W, P118KX, B, D, G, P, W, P119JC, P100 Series, P1151E, B, D, G, W, VPG Series: CKP1B, CKP1T, CKP1W, VPC-X Series: X131, X131KX, B, N, P, S, X135,									
C	19V	Dell									
<p>Inspiron: Inspiron B120, Inspiron B130, Inspiron 1000, Inspiron 1200, Inspiron 1300, Inspiron 2200, Inspiron 3000 series, Inspiron 3200, Inspiron 3500 series, 7000 series Inspiron E1405, Inspiron E1505, Inspiron E1705, Inspiron 13Z, Inspiron 14Z, Inspiron 15Z, Inspiron 1150, Inspiron 1320, Inspiron 1410, Inspiron 1420, Inspiron 1440, Inspiron 1470, Inspiron 1501, Inspiron 1520, Inspiron 1521, Inspiron 1525, Inspiron 1526, Inspiron 1545, Inspiron 1570, Inspiron 1750, Inspiron 1750, Inspiron 6000, Inspiron 6400, Inspiron 8500 Series, Inspiron 8600 Series, Inspiron 9200 Series, Inspiron 9300 Series, Inspiron 9400 Series, Inspiron 300M, Inspiron 510M, Inspiron 600M, Inspiron 630M, Inspiron 640M, Inspiron 700M Series, Inspiron 710M</p>											



Notebook Connector Compatibility List

Tip	Sony VAIO	Tip	Toshiba	Tip	Toshiba	Tip	Toshiba
A 16V	VGN-TXN15P, VGN-TXN17P/L, VGN-TXN19P/L, VGN-TXN25N, VGN-TXN27N, VGN-TXN29N/L, TZ Series, VGN-T211MN/N, VGN-T211VN/X, VGN-T211XN/B, VGN-T221MN/N, VGN-T221VN/R, VGN-T221VN/X, VGN-T221WN/B, U Series, VGN-U, VGN-U50, VGN-U70P, VGN-U71P, VGN-U750, VGN-U750P, VGN-U8, VGN-U8C, VGN-U8G, UX Series, VGN-UX1XNX505 Series, VGN-X505, VGN-X505/ZP, VGN-X505VP, VGN-X505ZP, VGN-T155, VGN-T160, VGN-T160P/L, VGN-T160P/LKIT2, VGN-T170, VGN-T1XP/L, VGN-T1XP/T, VGN-T240, VGN-T240P, VGN-T240P/L, VGN-T250, VGN-T250/L, VGN-T250P/L, VGN-T250P/S, VGN-T260, VGN-T260P, VGN-T260P/L, VGN-T270, VGN-T270P, VGN-T270P/L, VGN-T277P, VGN-T2P/L, VGN-T2XP, VGN-T2XP/L, VGN-T2XP/S, VGN-T2XRP/S, VGN-T340, VGN-T340P, VGN-T340P/L, VGN-T350, VGN-T350/L, VGN-T350P, VGN-T350P/L, VGN-T350P/S, VGN-T350P/T, VGN-T360, VGN-T360/L, VGN-T360P, VGN-T360P/L, VGN-T370, VGN-T370P, VGN-T370P/L, VGN-T50B/L, VGN-T50B/T, VGN-T70B/L, VGN-T90PS, 800 Series, PCG-808, PCG-812, PCG-818, PCG-838800 Series, PCG-833L, PCG-873M, PCG-881L, PCG-881R, PCG-882L, PCG-883L, PCG-884L, PCG-885L F series, PCG-F150, PCG-F160, PCG-F180, PCG-F190, PCG-F250, PCG-F270, PCG-F280, PCG-F290, PCG-F340, PCG-F350, PCG-F360, PCG-F370, PCG-F390, PCG-F430, PCG-F450, PCG-F480, PCG-F490, PCG-F520, PCG-F540, PCG-F560, PCG-F580, PCG-F590, PCG-F610, PCG-F630, PCG-F650, PCG-F680, PCG-F690 XG series, PCG-XG8, PCG-XG9, PCG-XG500, PCG-XG700, PCG-XG18, PCG-XG19, PCG-XG28, PCG-XG29, PCG-XG38, XG39, XG500, XG700FX series, PCG-FX55, PCG-FX100, PCG-FX120, PCG-FX140, PCG-FX150, PCG-FX170, PCG-FX190, PCG-FX200, PCG-FX201, PCG-FX210, PCG-FX215, PCG-FX220, PCG-FX240 PCG-FX250 PCG-FX250K PCG-FX270 PCG-FX275 PCG-FX290K, PCG-FX300, PCG-FX310, PCG-FX340, PCG-FX370, FX-370P, PCG-FX390, PCG-FX400, PCG-FX410, PCG-FX430, PCG-FX700, PCG-FX770, PCG-FX776, PCG-FX800, PCG-FX876, PCG-FX880, PCG-FX900, PCG-FX905FXA Series:, PCG-FXA32, PCG-FXA33, PCG-FXA35, PCG-FXA36, PCG-FXA47, PCG-FXA48, PCG-FXA49, PCG-FXA53, PCG-FXA59, PCG-FXA63R505 Series, PCG-R505, PCG-R505BF, PCG-R505D, PCG-R505DF, PCG-R505DFK, PCG-R505DL, PCG-R505DLK, PCG-R505DS, PCG-R505DSK, PCG-R505E, PCG-R505EC, PCG-R505ECK, PCG-R505EL, PCG-R505ELK, PCG-R505ESK, PCG-R505G, PCG-R505GC, PCG-R505GCK, PCG-R505GL, PCG-R505GLK, PCG-R505JE, PCG-R505JEK, PCG-R505JL, PCG-R505JL, PCG-R505JLK, PCG-R505JS, PCG-R505JSK, PCG-R505JSP, PCG-R505TE, PCG-R505TEK, PCG-R505TL, PCG-R505TLK, PCG-R505TS, PCG-R505TSKZ505 Series, PCG-Z505, PCG-Z505HE, PCG-Z505HS PCG-Z505HSK, PCG-Z505JE PCG-Z505JEK, PCG-Z505JS PCG-Z505JSK, PCG-Z505LE PCG-Z505LEK, PCG-Z505LS PCG-Z505LSK, PCG-Z505R PCG-Z505RX PCG-Z505S PCG-Z505SX	B 15V	Tecra Series: 500 series, 520, 520CDS, 520CDT, 530CDS, 530CDT, 550, 550CDT 700 series, 700, 700CS, 700CT, 710CDT, 720, 720CDT, 730CDT, 730XCDT, 740, 740CDT, 750, 750CD, 750CDM, 750CDT, 750DVD, 780, 780CDM, 780CDT, 780DVD8000 series, 8000, 8100, 8200 Satellite Series, 1800, 1850, 1850C, T4500, T4500C, T4600, T4600C, 4280ZDVD200s series, 220, 220CDS, 225, 225CDS, 230, 230CDS, 230CX, 235, 235CDS, 250300s series, 300, 300CDS, 305, 305CDS, 305CDT, 310, 310CDS, 310CDT, 315, 315CD, 315CDS, 315CDT, 320, 320CDS, 320CDT, 320CT, 325, 325CDS, 325CDT, 330, 330CDS, 330CDT, 335, 335CDS, 335CDT1500 Series, 1500, 1555, 1555CDS, 2000 Series, 2060CDS, 2060CDT, 2065CDS, 2065CDT, 2100, 2100CDS, 2100CDT, 2100CDX, 2105CDS, 2105CDT, 2115, 2115CDS, 2140, 2140CDT, 2140XCD, 2180, 2180CDT, 2210CDT, 2210XCD, 2250CDT, 2250XCD, 2410, 2410-S203, 2410-S204, 2410-S205, 2410-S206, 2415, 2415-S205, 2450, 2455, 2455-S3001, 2455-S305, 2455-S306, 2520, 2520CDT, 2450, 2455, 2455-S3001, 2455-S305, 2455-S306, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510CDS, 2410CDS/4, 2515CDS, 2415CDS/4, 2515CDT, 2515CTS, 2530CDS, 2530CDS/4, 2535CDS, 2535CDS/4, 2535CDT, 2540CDS, 2540CDS/4, 2540CDT, 2545CDS, 2545CDS/4, 2545CDT, 2545XCDT, 2590CDS, 2590CDS/4, 2590CDT, 2590XDVD, 2595CDS, 2595CDS/4, 2595CDS, 2595CDT, 2595XDVD, 2610-2675, 2610DVD, 2615DVD, 2655XDVD, 2675DVD, 2715, 2715DVD, 2715XDVD, 2710XDVD, 2755DVD, 2755XDVD, 2770XDVD, 2775XDVD, 2800, 2800-S201, 2800-S202, 2800-S210, 2805, 2805-S201, 2805-S301, 2805-S302, 2805-S401, 2805-S402, 2805-S5034000 Series, 4000 4000CDS, 4000CDS/4, 4000CDT, 4000SCTS/4, 4005CDS, 4005CDS/4, 4005CDT, 4010CDS, 4010CDS/4, 4010CDT, 4015CDS, 4015CDS/4, 4015CDT, 4020, 4020CDT, 4020CDT/6, 4025CDT, 4025CDT/6, 4030CDT, 4030CDT/4, 4035CDT, 4060, 4060CDT, 4060CDT/4, 4060XCDT, 4070, 4070CDS, 4070CDT, 4080, 4080CDT, 4080XCDT, 4080XCDT/6, 4085, 4085XCDT, 4090, 4090CDS, 4090XCDT, 1090XDVD, 4090XDVD/6, 4100, 4100XCDT, 4100XDVD, 4100XDVD/6, 4200, 4260, 4260DVD, 4280, 4280XDVD, 4280ZDVD, 4300, 4320ZDVD, 4340ZDVD, 4360ZDVD, 4400, 4400CDT, M20-258, 4400, 4400CDT, M20-258, 4400, 4400CDT, A80, A85, A100 series, A100-S2211, A105, A105-S1012, A105-S1013, A105-S1014, A105-S171, A105-S1712, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S361, A105-S3611, A100, A100-05R010, A100-016004, A100-03501N, A100-046004, A100-151, A100-153, A100-155, A100-158, A100-159,	B 15V	A100-161, A100-163, A100-165, A100-166, A100-168, A100-169, A100-170, A100-175, A100-181, A100-188, A100-192, A100-193, A100-209, A100-212, A100-218, A100-220, A100-232, A100-233, A100-234, A100-237, A100-250, A100-252, A100-253, A100-269, A100-270, A100-500, A100-507, A100-508, A100-510, A100-521, A100-522, A100-523, A100-525, A100-528, A100-529, A100-533, A100-534, A100-551, A100-JH2, A100-LE1, A100-LE4, A100-LE6, A100-S2211TD, A100-S2311TD, A100-S8111TD, A100-SP621, A100-ST2311, A100-ST3211, A100-ST8211A105 series, A105-S101, A105-S171, A105-S271, A105-S361, A105-S1013, A105-S1014, A105-S1712, A105-S2001, A105-S2011, A105-S2021, A105-S2031, A105-S2051, A105-S2061, A105-S2081, A105-S2091, A105-S2111, A105-S2711, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S3611A110, A200 series, A200-1Y0 A200-27R A210-19T A300 series, A300-111 A300-1MC A300-10M A300-1RY A300-21H A300-211 A350-11N A350-12J A350-20N1L0, L15, L20, L25, L40 series, L40-14N L40-17U L40-18ZL300 series, L300-11C L300-13R L300-147 L300-148 L300-149 L300-14G L300-16L L300-18D L300-18E L300-19Y L300-1AP L300-1AQ L300-1AS L300-1BV L300-1BW L300-1CU L300-1DI L300-1DN L300-1DU L300-1FS L300-1G5 L300-1G6 L300-1G8 L300-1G9 L300-20D L300-20W L300-215 L300-217 L300-227 L300-229 L300-22XL300-25G L300-25H L300-26M L300D-10Q L300D-11V L300D-12L L300D-202L350 series, L350-12N L350-145 L350-14F L350-159 L350-170 L350-171 L350-17P L350-17R L350-203 L350-20F L350-20G L350-212 L350D-12M L350D-131M30 series, M30X, M30X-40, M30X-60, M30X-80, M30X-S114, M30X-S1592, M30X-1593, M30X-S171, M30X-S181, M30X-S191, M30X-214, M30X-S221, M30X-S234, M30X-SP114M35X, M35X-S109, M35X-S109, M35X-S111, M35X-S114, M35X-S1141, M35X-S1142, M35X-S1143, M35X-149, M35X-S1492, M35X-S161, M35X-S163, M35X-S309, M35X-S311, M35X-S329, M35X-S349, M35X-SP114, M35X-SP161, M35X-SP171, M35X-SP181, M35X-SP311M40-S312TD, M45, only M45-S165, M45-S165XM55, only M55-S139, M55-S139X, M55-S141, M55-S1001M60 series, M60-103, M60-104, M60-105, M60-112, M60-126, M60-128, M60-131, M60-132, M60-134, M60-135, M60-139, M60-144, M60-148, M60-149, M60-153, M60-154, M60-161, M60-163, M60-164, M60-167, M60-169, M60-170, M60-171, M60-175, M60-176, M60-BK3, M60-CD4, M60-CD6, M60-CD7, M60-S811ST, M60-S6111TD, M60-S8112ST, M60-S8112TDM65 series, M65-S809, M65-S909, M65-S8091, M65-S9062, M65-S9063, M65-S9064, M65-S9065, M65-S9091, M65-S9092, M65-S9093, M65-SP811, M65-SP959M105 series,	B 15V	A200-1X1 A200-1X2 A200-1YK A200SE-1X6 A200SE-1X8 A210-16V A210-16W A210-18M A210-1AZ A210-1B1 A210-1B3 A210-1C7, Pro A300 series, Pro A300-192 A300-193 A300-194 A300-195 A300-1A8 A300-1C1 A300-1C2 A300-1DZ A300-1E0 A300-1EA A300-1FZ A300-1G0 A300-1LW A300-1NG A300-1NH A300-1O9 A300-10P A300-10Q A300-1PW A300-1RR A300-1RS A300-1SX A300-229 A300-22C A300-22E A300-249 A300D-131 A300D-132 A300D-13E A300D-13S, Pro L300 series, Pro L300-128 L300-12F L300-12H L300-12I L300-12X L300-152 L300-153 L300-154 L300-155 L300-156 L300-19Q L300-19S L300-1AD L300-1AF L300-1AI L300-1DS L300-1FJ L300-1FK L300-1FL L300-1FN L300-1FO L300-21F L300-23L L300-23M L300-25K L300-26R L40-15A L40-15C L40-15D, Pro L40 series, Pro L40-15A L40-15C L40-15D L40-15E L40-17E L40-only M105-S105XU300 series, U400 series, P200D series, P200D-127 P200D-137 P300-19N P300-20C P300-20H P300-23L, Pro A200 series, Pro 17F L40-17G L40-17H L40-18M L40-19I L40-190, Pro P300 series, Pro P300-14P P300-14Q P300-14R P300-14S P300-18N P300-18O P300-18P P300-18Q P300-1CV P300-1EX P300-1FP P300-1FQ, Pro U400 series, Pro U400-10H U400-11V U400-126 U400-127 U400-12Y U400-130 U400-13A U400-142 U400-153 U400-15I U400-170 U400-17Q U400-18L U400-18S U400-23X Equium Series, A200-26D, L40 series, L40-14I L40-156 L40-17ML300 series, L300-146 L300-17Q L350-10L L350D-11DP300 series, P300-16T P300-190 U400-124 U400-145 U400-146 Portégé Series: 300 series, 300CT, 305CT, 310CT, 315CT, 320CT, 325CT, 330CT, 335CT, 600 series, 650, 650CT, 660, 660CT, 660CT, 600CT, 610, 610CT, 620, 620CT, 2000 series, 7000 series, 7000CT, 7010CT, 7015CT, 7020CT, 7140CT, 7200CT, 7200CTE, 7220CTE, T3000 series, T3400C, T3400CT, T3600CT
19.5V (19V)						C 19V	Tecra Series: L2 series Pro 440, Pro: 440, 440CDT, 440CDX, 445CDT, 445CDX, 450CDT, 450CDX, 460CDT, 460CDX, 465CDT, 465CDX, 470, 470CDT, 480CDT, 480CDX, 485CDT, 485CDX, 490CDT, 490CDX, 490XCDT, 495CDT, 495CDX, 4200, 4260DVD, 4270, 4270DVD, 4270XDVD, 4280XDVD, 4280ZDVD, 4300, 4320, 4320ZDVD, 4340, 4340ZDVD, 4360, 4360ZDVD Portégé Series, M800 series